AWNING LOCK 2

A another simply way to lock your awning tube gear head. Some awnings may not have this factory hole.

This trick will lock the tube in place and keep it from unrolling.



Insert the awning pull rod into the hole in the end of the roller tube.

This is the hole that the awning fabric slides into. Some newer models may not have this hole.



The lower end of the rod can be wrapped with electrical tape to keep from scratching the support arm.

Scroll down to page 2



The rod is wrapped around the support arm and secured with velcro straps. Besides locking the roller it provides a place to store the rod.